




EX-510 MOH Cable

For AT&T SB67118, SB67138, and SB67158

Select music on hold source

- 1- Connect the EX-510 to the Headset Jack on the SB67138. This MUST be done FIRST!






- 2- When the telephone is idle, press **MENU/ENTER**.
- 3- Press UP or DWN arrow to scroll to **Base setup**. Press **MENU/ENTER**.
- 4- Press UP or DWN arrow to scroll to **Music on hold**. Press **MENU/ENTER**.
- 5- Press UP or DWN arrow to scroll to **M.O.H. source**. Press **MENU/ENTER**.
- 6- Press UP or DWN arrow to highlight **Aux In Device**.

Display will read “**Device connected to the headset jack will be used for M.O.H.**”

Press **MENU/ENTER** to SAVE.

NOTES:

- 1- If you unplug the audio cord from the headset jack, the ON HOLD source is immediately re-set back to the internal music. If you RE-INSERT the cord, you will have to go back and re-program it for the external source.
- 2- When using an external audio source, the audio will play a little louder for the first 4 seconds. This is normal and is a function of the telephone.



If you don't get MOH then make sure that MOH is turned ON by:

- 1- When the telephone is idle, press **MENU/ENTER**.
- 2- Press UP or DWN arrow to scroll to **Base setup**. Press **MENU/ENTER**.
- 3- Press UP or DWN arrow to scroll to **Music on hold**. Press **MENU/ENTER**.
- 4- Press **MENU/ENTER** again to select **M.O.H. on/off**.